

REMOVING OIL STAINS

Concrete pavers on driveways stained by oil leaking from cars aren't damaged by petroleum products, but the stains can be difficult to remove. Stains should be treated as soon as possible since the



Photo courtesy Resiblock

longer they remain on the surface, the deeper they penetrate and the harder they are to remove. Wipe excess oil from the surface as soon as possible and apply liquid detergent. Allow it to soak for several minutes. Then wash the pavers with hot water.

Several treatments may be necessary for particularly stubborn stains. Cleaners specially made for removing oil stains from concrete pavers are recommended since they yield good results. In some cases, it may be simpler to replace the stained pavers with new ones.

Removing oil and many other stains are discussed in Tech Spec 5—*Cleaning and Sealing Interlocking Concrete Pavement—A Maintenance and Protection Guide*, and a thorough review of stain removal is covered in the booklet, *Removing Stains from Concrete*.

Cleaning and sealing concrete pavers early in their life can make removing stains easier since sealers prevent stains from soaking into the surface. However, the sealers may need to be reapplied from time to time due to wear and weather. Concrete pavers should be cleaned prior to applying a sealer to obtain the best performance and appearance. Your paver source can provide information on cleaners and sealers specifically made for concrete pavers. Tech Spec 5 provides guidance on the types and applications of cleaners and sealers. Contact your supplier for availability of Tech Specs and other ICPI literature.

© Copyright 1999 Interlocking Concrete Pavement Institute



1444 I Street, NW - Suite 700
Washington, DC 20005-2210
Tel: 202-712-9036
Fax: 202-408-0285
E-mail: ICPI@bostromdc.com
Web site: www.icpi.org



Your concrete paver source:

Oldcastle Foster Southeastern

46 Spring Street
Holbrook, MA 02343
P: 800.462.2225
F: 781-767-2991



*A Maintenance Guide
for Consumers*

THE BEST PAVING SYSTEM

Quality concrete pavers make a surface that can last for generations when

placed on a well-prepared base. They need practically no maintenance when installed to guidelines set by the Interlocking Concrete Pavement Institute (ICPI). As with all pavements, sometimes maintenance is necessary. This guide will help you get the most value from your concrete paver installation.

JOINT SAND

During the course of normal use, the sand-filled joints receive dirt from traffic on the pavement. Dirt settles into the top of the joints, helping to hold the sand in place. Installations exposed to driving winds or runoff, however, may lose some joint sand that can be simply replenished with dry sand. If the problem recurs, sealers will help hold the sand in the joints. These are applied over the entire paver surface as a liquid and allowed to soak and cure in the joints. Ask your concrete pavers source about these products and their application.

PREVENTING WEEDS AND ANTS

Weeds can germinate between pavers from wind-blown seeds lodged in the joints. They don't grow from the bedding sand, base or

soil. Weeds can be removed by hand or with herbicides. Take care in using herbicides so that adjacent vegetated areas are not damaged. Use biodegradable products that won't damage other vegetation or pollute water supplies when washed from the pavement surface. Besides stabilizing the joint sand, sealers can prevent seeds from germinating, and prevent ants from entering.

COLOR AND WEAR

Color in concrete pavers is achieved by adding pigment to the concrete mix during production. The cement in the concrete mix holds the pigments in place. They are very stable, showing little

change in their properties over time. As the paver wears from traffic or weather, the cement and pigment particles are gradually eroded causing a color change over time.

Like all pavements, concrete pavers receive dirt from foot or tire traffic which changes the surface color. One way to moderate the rate of color change is by cleaning and sealing the surface of the concrete pavers. Besides enhancing their color, sealers can prevent dirt from lodging in the surface.

SETTLEMENT AND UTILITY REPAIRS

Settlement is often caused by inadequate soil or base compaction. Other factors can be water in the base or soil, too thick a layer of bedding sand, or washed out bedding and joint sand. Loose or inadequate edge restraints will cause pavers to move apart.

Pavers in uneven areas can be removed, the settlement adjusted, and the units reinstated with no wasted paving materials or unsightly patches. If the base or soil has settled and is stable, remove the pavers and bedding sand, place and compact additional base material to the correct level, then add bedding sand. Bedding sand alone shouldn't be applied to adjust the level of the surface if its thickness exceeds 1½ in. (40 mm).

Concrete pavers can be removed for access to underground utilities, and reinstated after repairs. When utility repairs are complete, fill the trench with base material and compact it. Remove about 18 in. (0.5 m) of pavers on either side of the opening, level the bedding sand and replenish as necessary. Reinstall the pavers, compact, fill the joints with sand and compact the surface again, filling joints as needed. ICPI Tech Spec 6—*Reinstatement of Interlocking Concrete Pavements*, provides step-by-step guidelines on removal and replacement of concrete pavers.



EFFLORESCENCE

Efflorescence comes from free lime released from within the concrete units. It's dissolved and carried by water to the surface of the paver, leaving a white residue after the water evaporates. It doesn't damage the concrete and it usually wears away with time. A detailed explanation of efflorescence can be found in the ICPI brochure *Managing Efflorescence*.

Efflorescence can be removed with cleaners specially made for concrete pavers. Use care when applying them because many contain detergents and diluted acid. Contact your paver source for further information on efflorescence cleaners. Additional information can be found in Tech Spec 5—*Cleaning and Sealing Interlocking Concrete Pavement—A Maintenance and Protection Guide*.



Before cleaning



After cleaning

SNOW AND ICE REMOVAL

Concrete pavers offer outstanding freeze-thaw resistance. They endure de-icing salts much better than most pavement surfaces. Snow and ice are removed with shovels or plows like any other pavement. Electric or liquid snow-melting systems work well under concrete pavers, eliminating plowing while reducing slip hazards. Further information can be found in ICPI Tech Spec 12—*Snowmelting Systems for Interlocking Concrete Pavements*.

